

# Instructions for using the TakeAway Disco Bluetooth Receiver

To help you understand these instructions, here's what is meant by "receiver" and "phone"

- RECEIVER - this is device pictured which receives the Bluetooth signal and plays it through the speakers
- PHONE - to keep it simple, we use the word phone throughout these instructions - of course, it could be any phone, tablet, laptop, etc with Bluetooth playback



---

Before you connect

- There is a maximum range of 10 metres between your phone and the receiver. As you get close to 10 metres away the signal will stutter. If this happens for too long it is likely that your phone will stop playback and disconnect from the receiver. This means you'll have to reconnect and the music will be off for a while.
- If you notice that the signal stutters then move your phone closer to the receiver as soon as possible

Charging

- The receiver should be fully charged when you hire from us. It can last up to 13 hours "in ideal conditions" but we recommend that you plug it so that the battery doesn't run out
- Plug in the receiver to a Micro USB charger (the same as many phones use) - it will begin charging when plugged in
- When the red light turns off it is fully charged but it's fine to leave it connected to the charger

Powering on

- To power ON, hold down the button for 3 seconds - the light should flash pink 3 times

Pairing

- After it is powered on the light should flash red then blue alternately - this means it is in pairing mode
- NOTE: if the receiver is in pairing mode for 2 minutes and no phone is paired with it then it will switch off
- Turn on the Bluetooth setting on your phone (if it isn't already on)
- Search on your phone for "AUKEY BR-C1"
- There's usually no need to enter a PIN but if your phone requests it then enter "0000"
- When your phone is connected to the Bluetooth receiver the lights on the receiver will turn blue, without flashing
- It is now ready for you to play music from your phone
- **VERY IMPORTANT:** Set your phone to full volume after starting playback and adjust the volume from the speaker. If you don't do this then if another phone is connected it could be much louder and blow the speakers.

To connect a new phone

- Hold the button on the receiver down for 2 seconds and it will disconnect from the phone that it is currently connected to and enter pairing mode (red and blue lights flashing alternately)
- Follow the instructions above to connect the new phone

Powering off

- To power OFF, hold down the button on the receiver for 5 seconds - the light should flash pink 3 times and then turn off